



NOTES:

1. EXTEND BOX AS FAR IN FRONT OF SUPPORT POST AS POSSIBLE TO PREVENT SNOW PLOW DAMAGE.
2. LIST ADDRESS ON SIDE OF BOX FROM WHICH CARRIER APPROACHES OR ON THE FRONT WHERE BOXES ARE GROUPED. LETTERS SHALL BE A MINIMUM 1" HIGH.
3. POST SHOULD BE DIRECT-BURIED IN SOIL AND NOT ANCHORED IN CONCRETE.
4. PLACE BOX SUCH THAT POSTAL CARRIER CAN SERVE WITHOUT LEAVING VEHICLE.