



NOTES

1. INSTALL EXPANSION JOINTS:
 - ALONG ANY ABUTTING BUILDING
 - AT THE INTERSECTION OF TWO WALKS (ONE JOINT ONLY)
 - AROUND ANY STRUCTURE WITHIN THE FLATWORK
 - ALONG ONE SIDE OF ABUTTING CONCRETE DRIVEWAYS